



TECHNICAL DATA

UROXSYS MARINE BRUSH CLEANER

DESCRIPTION	A formulated solvent blend
USES	To preserve and clean brushes used for the application of the Uroxsys Marine Aliphatic and Uroxsys Marine Primer.
COLOUR	Clear
FEATURES	<ul style="list-style-type: none">● Mild odour● Excellent solvency● Prevents product 'curing' on brush during storage● Reusable
APPLICATION	<p>Remove excess product from brush. Put sufficient brush cleaner into a container to ensure the bristles are covered. Push the brush against the bottom of the container to flex and open the bristles, working the product right into the core.</p> <p>For wet storage, leave brush soaking. Prior to reuse, work out excess cleaner, and spin/shake dry.</p> <p>For dry brush storage, leave soaking overnight. Remove excess product, rinse brush thoroughly with fresh brush cleaner. Shake out and dry.</p>

TECHNICAL DATA

Specific Gravity:	0.87
Flash Point:	14°C
UN No.:	1263
DG Class:	3a
Category:	Fourth Schedule, Harmful substance
Packaging:	1 litre

SAFETY DATA: Flammable liquid. Use in well ventilated areas only. Can defat skin and cause irritation. For detailed information, consult the Material Safety Data Sheet, available on request from Uroxsys Ltd.

DISCLAIMER: This information is, to the best of our knowledge, true and accurate, but any recommendations or suggestions which may be made are without guarantee, since the conditions of use are beyond our control. Furthermore, nothing contained herein shall be construed as a recommendation to use any product in conflict with existing patents covering any material or its use.

MBC TD1 APR 08